



1. Install one ten foot stick out of ground at service pole. Provide the additional following for BCES to install:
 1. 2 x Ten Foot Stick 3" Schedule 80 Gray PVC
 2. 4 x 3" Conduit Straps
 3. 1 x 3" PVC Weatherhead
2. Warning Undergroud Plastic Marker should be placed in ditch one foot above underground pipe, provided by BCES.
3. This applies to ALL underground services.